

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5






FIG. 6




**FIG. 7**

<STARTUP.MLS>



**FIG. 8**

<STARTUP.MLS>



**FIG. 9**

SYSTEM PARAMETER	MEANINGS
0	Menu Description Language Code(M_LCD)
1	Audio stream number(ASTN) for Title Domain(TT_DOM)
2	Sub-picture stream number(SPSTN) and On/OFF flag for TT_DOM
3	Angle number(AGLN) for TT_DOM
4	Title number(TTN) for TT_DOM
5	VTS Title number(VTS_TTN) for TT_DOM
6	Title PGC number(TT_PGCN) for TT_DOM
7	Part_of Title number(PTTN) for One_Sequential_PGC_Title
8	Highlighted Button number(HL_BTNN) for Selection state
9	Navigation Timer(NV_TMR)
10	TT_PGCN for NV_TMR
11	Player Audio Mixing Mode(P_AMXMD) for Karaoke
12	Country Code(CTY_CD) for Parental Management
13	Parental Level(PTL_LVL)
14	Player Configuration(P_CFG) for Video
15	P_CFG for Audio
16	Initial Language Code(INI_LCD) for Audio Stream(AST)
17	Initial Language Code extension(INI_LCD_EXT) for AST
18	INI_LCD for Sub-picture Stream(SPST)
19	INI_LCD_EXT for SPST
20	Player Region Code
21	Initial Language Code(INI_LCD) for ENAV Application
22	
23	

**FIG. 10**




FIG. 11

